

Assembly data

- Apply corrosion protection to pipe line.
- Insert pipe, pull protective film from insulation and glue.
- Screw together clamp parts.
- On front side, glue sealing insulation to refrigeration clamp.