

## Assembly data

- Introduce the T-head bolt into the rail or bracket from the side.
- After alignment, the T-head bolt should be secured with the nut.