

Type	B1	B2	C	D	E1	E2	F1 [kN]	G	H	H1	K	L	L1	M	N	R	S	Course d'ajustement [mm]
1	15-23	34-42	19	5,3	15-23	34,0-42,0	2	4,5	22,5	33	6	31	130	28	41	4,5	45	8
3	32-44	67-79	19	7,1	40-52	74,5-86,5	3	5,5	23,0	36	13	40	230	32-35	46	5,5	98	12
5	26-40	57-71	29	12,0	28-42	58,5-72,5	5	11,0	49,0	70	13	55	308	60	88	8,0	144	14

