

Tipo	A	B min.	B max.	D	E	F1 [kN]	F2 [kN]	H	H1	HUB	HW min.	HW max.	K	L1	L2	L3	M min.	M max.	M2	N	P	Parafusos de aperto
0	6,5	17,0	33,0	4,5	13	0,8	0,8	12	47	16	12	20	6,5	66,0	10	52	-	16,0	M10x1,0	25	16	M 4x20
1	8,0	24,5	44,5	4,5	20	1,0	1,0	15	60	20	12	20	7,0	91,0	16	72	16	19,5	M12x1,5	30	20	M 4x20
2	10,0	32,5	57,5	5,6	25	2,0	2,0	20	95	26	17	25	12,5	114,0	19	105	-	36,0	M16x1,5	50	34	M 6x25
3	12,0	37,0	69,0	6,5	30	2,5	2,5	25	110	32	22	35	13,0	140,0	22	129	30	42,0	M20x1,5	60	30	M 8x35
5-M27	16,0	41,5	81,5	8,5	50	4,5	4,5	30	126	40	30	50	15,0	171,5	25	142	30	45,0	M27x2,0	65	35	M12x50

