

Tipo	A	B	E	F1 [kN]	F2 [kN]	H	H1	HUB	HW min.	HW max.	L1	L2	L3	M	M2	N	Parafusos de aperto
2	10	35	15	1,0	1,0	24	76	21	18	27	70	13	82	M 6	M16x1,5	31	M 6x25
3	12	56	25	2,5	2,5	33	128	40	22	35	110	16	130	M 8	M20x1,5	33	M 8x35
5-M27	16	92	35	4,0	4,0	37	148	67	30	50	175	24	138	M12	M27x2,0	50	M12x50

