

Assembly and disassembly of the Tufnut®

For assembly always two identical nuts are needed, one of them can be used multiple times.

1. Screw the first nut onto the bolt by hand
2. Install the second nut upside down onto the bolt to approximately a half-turn distance from the first nut, resulting in a diabolical shaped unity
3. Torque the unity with an adjustable wrench
4. Remove the upper nut

The nut can be removed by carrying out the above steps in reverse order.

