Assembly data

Level adjustment is possible by turning the threaded pin.

Hold threaded parts together, slide parallel connector over.
Secure using lock nut.